



300 Gallons

****If you have well water or high minerals, use Metal Magic while filling. Run the spa for minimum of 6 hours, clean the filters, then continue the start-up process.****

Frog @Ease Deluxe System

START-UP

- Add **3 oz. METAL MAGIC** to remove metals and prevent scaling.
- Add **2 oz. PH DOWN/PH UP** every 3 hours to lower or raise Total Alkalinity and pH levels until they are in the ideal range based on test strip.
- Add **1 packet JUMP START** to establish a chlorine residual of .5 – 1.5ppm.
- Set **@EASE CARTRIDGE** to #2
- Add **12 oz. (2 pouches) GENTLE SPA**.

WEEKLY MAINTENANCE

- Make sure water is balanced. Adjust pH and Alkalinity per Test Strip
- Add **1 oz. (2 capfuls) SKY BLUE CLARIFIER** weekly.
- Add **1 large capful SPA PERFECT** weekly.
- Add **1 Packet FROG MAINTAIN (SHOCK)** weekly.

MONTHLY MAINTENANCE

- Replace **SMARTCHLOR CARTRIDGE** (gray cartridge)
- Replace **MINERAL CARTRIDGE** (blue cartridge) every 3-4months.
- Make sure spa filter is clean

980 Orientation



Chemical Start-up

